

WELDING FLUX RECOVERY SYSTEM

- Requires compressed air 50-100 psi - air version
- Stop wasting Flux
- Easily adapted to all Subarc systems
- No moving parts - air version
- 1.1kw - electric version
- Direct recycling of flux back to hopper
- Easy to use
- No electrical input required - air version
- Comes with its own flux hopper
- Add additional flux while in operation
- Some assembly required



Part No	Description
LTHJ-B2	Welding Tractor Flux Recovery Machine - air
LTHJ-B1-2	Welding Tractor Flux Recovery Machine - electric

Set Inclusions



- 1 x Flux pick-up nozzle
- 1 x Bracket
- 1 x Dust bag
- 1 x Ø38 hose 0.8m
- 1 x Flux Hopper
- 1 x Flux Trowel